

# Heirloom Side Table with Door

Style # 760-802 (Medium Brown) DPCI # 074-05-0515

Assembly Instructions



**CONGRATULATIONS - You've purchased a fine furniture item from**




**We have designed our furniture with you, the Target guest in mind. Our clear, easy to follow, step by step instructions will guide you through the project from start to finish. Feel confident that this will be a fun and rewarding project. The final product will be a quality piece of furniture that will go together smoothly and give years of enjoyment.**

**All you need is a standard screwdriver, phillips screwdriver and a hammer.**

**If you have questions, just call 1-800-782-3876 or e-mail [CSupport@Thomasville.com](mailto:CSupport@Thomasville.com) between 8:00a.m. - 9:00p.m., Monday - Friday and 9:00a.m. - 5:00p.m., Saturday (Eastern Time) for parts and services. Please refer to the DPCI code when calling.**


Screws are shown actual size. Hardware may be shown smaller than actual size.  
 Note: For reasons of manufacturing efficiencies, you may find extra hardware and unused holes in parts.




S2 1/2" Phillips-head Screw (20)  
003239




Touch Up Pen (1)  
002763




CH Cam Housing (8)  
009613




1-1/4" Hardware Bolt (1)  
80112378




MB Large L-Bracket (2)  
80092348



CS Cam Stud (8)  
009612




1-1/8" Round Washer-Head Screw (17)  
004518




Nail (20)  
002669




Cover-cap (4)  
80112382




Magnetic Catch Set (1)  
MC Magnetic Catch,  
SP Strike Plate  
Screws  
008075




LB L-Bracket (2)  
80112822



LPN Locking Shelf Pins (4)  
004053




Knob (1)  
80112327




HG Hinge (2)  
002549

**Note:** All parts may not be identified with labels, but to help identify certain parts, you may see one or more types of labelling. One type is the peel-off label and the other is an ink-print on one of the unfinished edges.







**A Top (1)**  
19-7/8" x 16"  
011945B




**B Bottom (1)**  
16" x 14-1/8"  
021634B




**F Adjustable Shelf (1)**  
15-13/16" x 13-5/8"  
061505B




**D Left Side (1)**  
25-3/8" x 14-1/8"  
042522B



**C Right Side (1)**  
25-3/8" x 14-1/8"  
032522B



**O Back Panel (1)**  
22-1/2" x 17-1/16"  
80112414




**H Door (1)**  
18-7/8" x 17-5/16"  
80112419




**K1 Crown Front Molding (1)**  
19-1/8" x 2-1/8"  
80112415



**K Upper Side Molding (2)**  
14-3/4" x 2-1/16"  
80112416



**HH Bottom Front Molding (1)**  
19-1/4" x 4"  
80112417





**I1 Crown Back Rail (1)**  
17-3/16" x 1-15/16"  
411702B




**M Base Side Molding (2)**  
14-1/8" x 3-15/16"  
80112418

# 1 Case Assembly




## Action Required:

- \* **SEE FIGURE 1**...Insert (4) cam housings (CH) into the holes, as shown, in bottom (B).




# 2







## Action Required:

- \* **Note: Make sure slots in large L-Brackets (MB) are as shown in diagram**...Attach (2) large L-Brackets (MB) to bottom front molding (HH), using (4) screws (S2).
- \* Attach bottom front molding (HH) to bottom (B), as shown, using (4) screws (S2).



3




**Action Required:**

- \* **SEE FIGURE 1**...Insert (4) cam housings (CH) into the holes, as shown, in left and right sides (D & C).
- \* Screw (4) cam studs (CS) into the holes, as shown, in sides (D & C).


# 4



(14) 1-1/8" Round Washer-Head Screws




Phillips-Head Screwdriver





## Action Required:

- \* With a helper, attach upper and base side moldings (K & M), as shown, to left and right sides (D & C), using (14) 1-1/8" screws.

5



Standard Flat-Head Screwdriver




**Action Required:**

- \* Attach bottom (B) to left side (D).
- \* Lock cam housings with a half turn clockwise of a standard flat-head screwdriver.
- \* Attach right side (C) to bottom (B).
- \* Lock cam housings.

# 6

## Top Assembly



(3) 1-1/8" Round Washer-Head Screws




Phillips-Head Screwdriver

**IMPORTANT...**  
Make sure small holes in rail (I 1) are facing, as shown.

### Action Required:


- \* **SEE IMPORTANT NOTE**...Attach crown back rail (I 1) to crown front molding (K1), as shown, using (3) 1-1/8" screws.



# 7



(4) Cam Studs (CS)




(2) L-Brackets (LB)



(4) 1/2" Phillips-Head Screws (S2)




Phillips-Head Screwdriver



### Action Required:

- \* Attach (2) L-Brackets (LB) to molding/rail (K1 & I 1), using (2) screws (S2).
- \* **Loosely**, attach molding/rail (K1 & I 1) to top (A), using (2) screws (S2).
- \* Screw (4) cam studs (CS) into the holes, as shown, in top (A).


# 8



Standard Flat-Head Screwdriver

**Action Required:**

- \* Attach top (A) to left and right sides (D & C).
- \* Lock cam housings.




# 9



Phillips-Head Screwdriver


**Action Required:**

- \* Tighten screws in L-Brackets in top (A) marked with arrows..
- \* **If adjustments to moldings (K & K1) are necessary, loosen screws adjust and retighten.**




Note: Make sure all cam housings are in the locked position.

10





(20) Nails



Hammer

Back Panel adds stability to case.



**Action Required:**

- \* With a helper turn unit with its front against the floor.
- \* Position back panel (O), **notch to the bottom of the unit**, even with the bottom edge of bottom (B).
- \* Make sure panel (O) fits square and even side to side. If it doesn't, adjust unit into square by pushing or pulling on one corner of the unit until back panel fits squarely.
- \* While nailing into pilot holes, take care to hammer nails in straight.


# 11




(4) Locking Shelf Pins (LPN)

### Helpful Hint...

Insert nub into the holes at the height you desire.



Adjustable Shelf rests on this portion of the shelf pin once the shelf is pushed down and locked in place.



### IMPORTANT


**Do not exceed the recommended weight limit on the designated panels. Exceeding this limit could cause sagging, possibly resulting in failure of the panels or bodily injury.**

#### Action Required:

- \* **SEE HELPFUL HINT...** To install adjustable shelf (F), push (4) locking shelf pins (LPN) into the holes at the height you desire.
- \* Position the shelf so it rests on top of the locking shelf pins and push down to lock in place.

# 12

## Door Assembly




(2) Hinges (HG)



(4) 1/2" Phillips-Head Screws (S2)



Phillips-Head Screwdriver





### Action Required:

\* Attach (2) hinges (HG) to door (H), as shown, using (2) screws (S2) in each hinge (HG).

# 13 a

(4) 1/2" Phillips-head Screws (S2)




(1) Magnetic Catch (MC) with (2) round-head screws  
(1) Strike Plate (SP) with (1) flat-head screw



(1) Knob

(1) 7/8" Hardware Bolt







Standard Flat-Head Screwdriver

## Option 1... Door opening from right to left

### Helpful Hint...

To secure knob to unit, hold knob while tightening bolt to allow nub to embed into wood.



### Action Required:

- \* With a helper, attach door (H) to unit, using (2) screws (S2) in each hinge.
- \* **SEE HELPFUL HINT**...Attach knob to door (H), using a 7/8" hardware bolt.
- \* **Adjustment may be made to door (H) by loosening screws in hinges, adjusting and retightening.**
- \* Attach magnetic catch (MC) to right side (C), using the round-head screws provided in the small plastic bag.
- \* Attach strike plate (SP), as shown, to door (H), using the flat-head screw provided in the small plastic bag.


# 13 b




(4) 1/2" Phillips-head Screws (S2)



Phillips-Head Screwdriver




(1) Magnetic Catch (MC) with (2) round-head screws  
(1) Strike Plate (SP) with (1) flat-head screw



(1) Knob




(1) 7/8" Hardware Bolt




Standard Flat-Head Screwdriver

## Option 2... Door opening from left to right



**Helpful Hint...**  
To secure knob to unit, hold knob while tightening bolt to allow nub to embed into wood.




### Action Required:

- \* With a helper, attach door (H) to unit, using (2) screws (S2) in each hinge.
- \* **SEE HELPFUL HINT...** Attach knob to door (H), using a 7/8" hardware bolt.
- \* **Adjustment may be made to door (H) by loosening screws in hinges, adjusting and retightening.**
- \* Attach magnetic catch (MC) to left side (D), using the round-head screws provided in the small plastic bag.
- \* Attach strike plate (SP), as shown, to door (H), using the flat-head screw provided in the small plastic bag.

# 14

\* Decorative cover caps are provided to cover exposed cam housings on finished panels.



That's it! You've finished assembling your Side Table with Door by



A **touch-up pen** has been provided for any touch up needed.

## Furniture Care Instructions:

Dust with a clean, lint-free cloth. Use a spray furniture polish as needed. Small nicks and scratches can be touched up with a furniture touch-up stick.